

Hire Torque Tools Victoria

Metric to Imperial Conversion

Fraction	Imperial	mm
0.063	1/16	1.6
0.125	1/8	3.2
0.1875	3/16	4.8
0.25	1/4	6.4
0.3125	5/16	7.9
0.375	3/8	9.5
0.4375	7/16	11.1
0.5	1/2	12.7
0.5625	9/16	14.3
0.625	5/8	15.9
0.6875	11/16	17.5
0.75	3/4	19.1
0.8125	13/16	20.6
0.875	7/8	22.2
0.9375	15/16	23.8
1	1	25.4
1.0625	1 1/16	27.0
1.125	1 1/8	28.6
1.1875	1 3/16	30.2
1.25	1 1/4	31.8
1.3125	1 5/16	33.3
1.375	1 3/8	34.9
1.4375	1 7/16	36.5
1.5	1 1/2	38.1
1.5625	1 9/16	39.7
1.625	1 5/8	41.3
1.6875	1 11/16	42.9
1.75	1 3/4	44.5
1.8125	1 13/16	46.0
1.875	1 7/8	47.6
1.9375	1 15/16	49.2
2	2	50.8
2.0625	2 1/16	52.4
2.125	2 1/8	54.0
2.1875	2 3/16	55.6
2.25	2 1/4	57.2
2.3125	2 5/16	58.7
2.375	2 3/8	60.3
2.4375	2 7/16	61.9
2.5	2 1/2	63.5
2.5625	2 9/16	65.1
2.625	2 5/8	66.7
2.6875	2 11/16	68.3
2.75	2 3/4	69.9
2.8125	2 13/16	71.4
2.875	2 7/8	73.0
2.9375	2 15/16	74.6

Fraction	Imperial	mm
3.0625	3	76.2
3.0625	3 1/16	77.8
3.125	3 1/8	79.4
3.1875	3 3/16	81.0
3.25	3 1/4	82.6
3.3125	3 5/16	84.1
3.375	3 3/8	85.7
3.4375	3 7/16	87.3
3.5	3 1/2	88.9
3.5625	3 9/16	90.5
3.625	3 5/8	92.1
3.6875	3 11/16	93.7
3.75	3 3/4	95.3
3.8125	3 13/16	96.8
3.875	3 7/8	98.4
3.9375	3 15/16	100.0
4	4	101.6
4.0625	4 1/16	103.2
4.125	4 1/8	104.8
4.1875	4 3/16	106.4
4.25	4 1/4	108.0
4.3125	4 5/16	109.5
4.375	4 3/8	111.1
4.4375	4 7/16	112.7
4.5	4 1/2	114.3
4.5625	4 9/16	115.9
4.625	4 5/8	117.5
4.6875	4 11/16	119.1
4.75	4 3/4	120.7
4.8125	4 13/16	122.2
4.875	4 7/8	123.8
4.9375	4 15/16	125.4
5	5	127.0
5.0625	5 1/16	128.6
5.125	5 1/8	130.2
5.1875	5 3/16	131.8
5.25	5 1/4	133.4
5.3125	5 5/16	134.9
5.375	5 3/8	136.5
5.4375	5 7/16	138.1
5.5	5 1/2	139.7
5.5625	5 9/16	141.3
5.625	5 5/8	142.9
5.6875	5 11/16	144.5
5.75	5 3/4	146.1
5.8125	5 13/16	147.6
5.875	5 7/8	149.2
5.9375	5 15/16	150.8

Fraction	Imperial	mm
6.0625	6	152.4
6.0625	6 1/16	154.0
6.125	6 1/8	155.6
6.1875	6 3/16	157.2
6.25	6 1/4	158.8
6.3125	6 5/16	160.3
6.375	6 3/8	161.9
6.4375	6 7/16	163.5
6.5	6 1/2	165.1
6.5625	6 9/16	166.7
6.625	6 5/8	168.3
6.6875	6 11/16	169.9
6.75	6 3/4	171.5
6.8125	6 13/16	173.0
6.875	6 7/8	174.6
6.9375	6 15/16	176.2
7	7	177.8
7.0625	7 1/16	179.4
7.125	7 1/8	181.0
7.1875	7 3/16	182.6
7.25	7 1/4	184.2
7.3125	7 5/16	185.7
7.375	7 3/8	187.3
7.4375	7 7/16	188.9
7.5	7 1/2	190.5
7.5625	7 9/16	192.1
7.625	7 5/8	193.7
7.6875	7 11/16	195.3
7.75	7 3/4	196.9
7.8125	7 13/16	198.4
7.875	7 7/8	200.0
7.9375	7 15/16	201.6
8	8	203.2



Torque Tools & Impact Sockets (Hire & Sales)

Head Office: Ph: 03 9710 1386 Mob: 0468 345 078

www.hiretorquetools victoria.com.au